



Chromo therapy LED control

The control is composed of a power control box and a keyboard.

When the control is connected to the power supply, the illuminated led indicates it is switched on (the control is on stand by).

The Chromo Light function is always enabled, regardless to the water level.

By pressing the button shortly, the spots switch on with white light (full-colour mode), then subsequent key presses select all remaining fixed colours and automatic programs, as explained below.

At any time, a long key press (2") turns the spots off.

Button click #	Type	Description
1	Manual Colour	White (full color)
2		Light Blue
3		Blue
4		Purple
5		Magenta
6		Red
7		Pink
8		Orange
9		Yellow
10		Apple Green
11		Green
12	Automatic Sequence	Sequence #1 "ENERGY"
13		Sequence #2 "TONIC"
14		Sequence #3 "RELAX"
15		Sequence #4 "SUN"

When stepping through the manual colours, the colour transition is short and gradual; additionally, at the beginning of any automatic sequence the spotlight is switched off and gradually ramps-up to the first colour of the sequence. This represents a "marker" to help the user distinguish an automatic sequence form a static manual colour. Within any automatic sequence, colour transitions are slow and gradual, much slower than in manual colours.

Chromo Automatic Sequences

Sequence ID	Colours	Step duration
1. ENERGY	Red	30"
	Orange	30"
	Yellow	30"
	White	30"
	Yellow	30"
	Orange	30"
	(repeat the sequence)	
2. TONIC	Yellow	30"
	Red	30"
	Green	30"
	(repeat the sequence)	
3. RELAX	Blue	30"
	Green	30"
	White	30"
	Green	30"
	(repeat the sequence)	
4. SUN	Yellow	20"
	Orange	15"
	Yellow	20"
	Light blue	15"
	Yellow	20"
	White	15"
	(repeat the sequence)	
5. DREAM	Green	60"
	Blue	60"
	Light blue	60"
	White	60"
	Orange	60"
	Red	60"
	Purple	60"
	(repeat the sequence)	