



INSTALLATION & USER INSTRUCTIONS TURBOJET SYSTEMS

LOG NO.

INSTALLATION

General information

All our turbojet whirlpool systems are supplied factory fitted and tested, as a final quality assurance the bath has been fully tested, examined, polished and then given extra protection on the roll surfaces and corners, then shrink wrapped.

The site installation of the whirlpool must be in accordance with the current IEE regulations, building regulations, local water authority bye laws as well as the relevant recommendations of British / European codes of practice.

Access must be provided for any future servicing requirements. The removal of any fixed panelling will be the responsibility of the customer. Do not lift the bath by any part of the whirlpool system.

Unpacking.

Carefully remove the packaging, you will have, whirlpool pump on integral stand (where possible), RCCB and cover and the remainder of the leg set (where supplied).

Any marks, defects or damage must be reported immediately to our customer service department prior to installation. No claims will be accepted thereafter.

Installation Instructions

After removing the packaging the bath can now be installed in accordance with the manufacturer's instructions.

With the pump being an integral part of the bath the only additional work required from a normal bath is to install the electricity supply. Certain baths will not accept a pump stand i.e. Armacast, steel, etc. in these cases the pump will be supplied separately with pump feet. You will need to build a platform for the pump, fit pump feet to pump and adjust as necessary and fit the pump to the system. **Tighten pump unions hand tight only.**

Electricity supply

All electrical work **must** be carried out by a qualified electrician in accordance with the current IEE regulations.

Brown	Live
Blue	Neutral
Green/yellow	Earth

Max load whirlpool pump	230v / 1100w
-------------------------	--------------

Optional extras:	
Spa blower	230v / 1050w
In line heater	230v / 1500w or 3000w
Underwater lights	12v / 35w

Your whirlpool system must be wired independently. Do not use the same power supply as other appliances.

The wiring must incorporate an RCCB with a 30ma trip, and a switched fused spur

You may have up to four wires to connect depending on optional extras chosen always ensure in line heaters have separate power supply.

All metal parts motor, legs etc must be earth bonded, and continuity checked.

Check mains voltage before connecting your system.

If the power supply cord is damaged it must be replaced by the manufacturers service agent or similarly qualified person.

Commissioning.

The electrical installation should have been undertaken by a qualified electrician, before operating your system for the first time ensure the RCCB is working correctly. This is done by pressing the test button on the RCCB unit, the RCCB should switch off. If not do not use the system further until the fault has been traced and rectified.

Fill the bath with hot water to a minimum 1 inch above the highest jet. Turn the whirlpool on by gently pressing and releasing the on/off button in the centre of the control. Let the system run for approx 15 minutes checking occasionally for leaks. During this time test air control and any other functions for correct operation.

Turn off the whirlpool and leave for a further 15 minutes check again for leaks.

Once satisfied complete the installation.

Please leave these instructions with the customer for future reference.



INVESTOR IN PEOPLE

USER INSTRUCTIONS

Thank you for choosing a **Turbojet hydro massage system** from Biojet International plc. Prior to using the system we recommend that you take a few moments to study your user instructions and familiarise yourself with the recommendations made herein in order to ensure you will get the best use from the product.

Safety check prior to use

Somewhere outside the room in which your whirlpool is situated there will be a residual current circuit breaker (RCCB). This will have been pointed out to you by your installer, with the power supply on press the test button on the RCCB. The RCCB should switch off. If this fails to happen do not use the system. Contact your electrician to check the installation. If in doubt please contact our customer service department.

Enjoying your whirlpool

Fill the bath to a minimum 1 inch above the highest jet, turning the whirlpool on with less water will cause splashing, to avoid causing damage to your bath due to thermal shock **always** run cold water into the bath first, then bring the water to bathing temperature with hot.

Bathing in the therapeutic waters of a whirlpool has many medical benefits, but it is recommended that the maximum time spent in a whirlpool is no longer than 30 minutes. You should not spend too long initially; build up to the maximum over a period of four weeks. Whirlpool baths should be taken after the rigours of the day as they induce a feeling of well being and promote a good night's sleep.

The medical benefits can be enhanced by the use of specially blended pure aromatherapy essences, normal bubble baths will froth excessively and should not be used, in general only products specially designed for whirlpools should be used in the bath. Special aromatherapy essences and lotions can be purchased direct from Biojet international plc or from your bathroom showroom

The jets in the system have an eyeball which is adjustable in direction, simply move the eyeball in the desired direction to alter the direction of the jet.

Controls



Turns your whirlpool system on and off and adjusts the water/ air ratio
Gently press and release the centre button to turn the whirlpool system on or off
Rotate the outer bezel to adjust the water/ air ratio minimum - maximum to alter the massage intensity



On / off control for spa system or underwater lights
Gently press and release to turn on or off



Air control for multi massage jets
Rotate between minimum and maximum for desired intensity.

Taking care of your Whirlpool

It is essential that regular cleansing of your whirlpool system is carried out; this is to prevent the presence and accumulation of bacteria. It is recommended the system is cleansed at least fortnightly more if your bath is used daily; Biojet International "Hygiene whirlpool cleanser" is available from your bathroom showroom or direct from Biojet international plc.

Do not: -

- Use abrasive cleaning products.
- Allow flannels or sponges to obstruct the suction filter.
- Allow small children to use the whirlpool unattended.
- Use bleach based sanitiser

AFTER SALES CARE AND STANDARD WARRANTY

The scope and terms of guarantee

Biojet International plc ("The Company") guarantees the product for a period of one year, Subject to the terms and conditions below.

The company shall:

Repair or replace free of charge the product or any component part, at its discretion, which shall in the opinion of the company have proved defective. The company shall be under no obligation whatsoever to repair or replace equipment which has been modified, altered or transformed in any way without the consent of the company in writing, or any component or accessory which has been replaced by a type not specified by the company. The company's liability under the guarantee is limited to the said repairs or replacement and shall under no circumstances extend to any financial loss or damage including consequential losses alleged to have been suffered by the claimant. The benefit of the guarantee is available only to the original purchaser of the equipment.

Where a guarantee claim is accepted by the company it will, at its option, repair or replace a component with the same equipment or its equivalent. The product must be installed, used and maintained in accordance with the relevant instructions as supplied with the product by the company.

The guarantee does not cover any component which in the opinion of the company has been neglected, misused, damaged, cleaned with an abrasive/acidic substance or restricted with lime scale or foreign matter. Chrome or gold finishes shall be covered against defects only for 1 year. No claim may be made under this guarantee in respect of fair wear and tear, or where the equipment has been repaired or serviced other than by a dealer or service engineer authorised by the company.

The company shall not bear any of the cost of removing or making good any panels, tiling or other devices which may hinder access to any component part.

Any component which is repaired or replaced shall be guaranteed for the remaining unexpired period of the guarantee only. The company will not be liable under the terms of this guarantee for products which have been used for commercial purposes, hire or reward.

The guarantee is only valid and enforceable in respect of Biojet International plc "factory fitted" equipment, which is purchased and used exclusively in the United Kingdom and Eire. The guarantee shall only be enforceable by you if the equipment has been purchased from an authorised dealer and not a subsequent purchaser. In the event of a claim for repairs or replacement being made under the terms of this guarantee in circumstances where in the opinion of the company the defect has not been caused by the company's materials or workmanship, the company reserves the right to charge the claimant at its current hourly rates and list prices in respect of any engineer's time and replacement parts. No authority has been given to any person, firm or company to vary the terms of this guarantee. This warranty is given in addition to and does not affect your statutory rights subject to United Kingdom law.